



ERROR DIAGNOSIS

TABLET DOES NOT RECEIVE A CYBERCON4 TOOL

- Tablet is switched on and bluetooth is active?
- Tablet meets the requirements (see operating instructions 4.1)?
- CyberCon4 app is installed on the tablet (see operating instructions 4.3)?
- CyberCon4 tool is in operation (see operating manual 3.)?
- The tablet is within range of the CyberCon4 tool (see operating instructions 8.)?

If you still cannot receive the CyberCon4 tool, either the Battery is empty or there is a defect.

VALUES ARE DISPLAYED INCORRECTLY

- If the CyberCon4 tool is geared down or geared, the drive speed of the machine differs to the drive speed of the CyberCon4 tool.
- The values are updated with a slight delay depending on the setting.

If the values are still incorrectly displayed, there is a defect.

BATTERY STATUS 0%

- If the battery status shows 0%, the CyberCon4 tool must be sent in for battery change (see operating manual 6.)



If the troubleshooting measures are unsuccessful, please contact:

EWS Weigele GmbH & Co. KG
Telephone +49(0)7161-93040-100
Mail service@ews-tools.de